



# Basic Sync Commands



These are the basic commands to use with your paired, Bluetooth-enabled mobile phone and your media player.



## Basic Voice Commands

After hearing "Please say a command," respond with your choice of mode:

"Phone"	To command paired, Bluetooth-enabled mobile phones
"USB" <sup>1</sup>	To command media players connected thru the Sync USB port
"Line-In" <sup>1</sup>	To select Sync's auxiliary input jack as a source for Sync
"Bluetooth Audio" <sup>1</sup>	To select a device capable of Bluetooth audio as a source for Sync
"Help"	To get spoken Sync help at any point
"Yes"	If Sync's confirmation is correct
"No" and repeat your original command	If Sync's confirmation is incorrect
"Cancel"	To stop Sync from acting on a command To stop Sync's current activity

## Bluetooth-Enabled Mobile Phones<sup>2</sup>

"Dial"	Then follow dialog with Sync to speak the area code + number and Sync will dial it
"Call + (name)"	To call a contact from your mobile phone's phonebook
"Read Message"	Read an incoming text message aloud
"Cancel"	Stop Sync from reading
Press or hold the PHONE button for 2-3 seconds <sup>3</sup>	End a call
Touch END <sup>4</sup>	End a call for a Navigation-equipped vehicle

## Media Players<sup>1</sup>

"Play"	To play at the beginning of a track or resume playing a paused track
"Play All"	To play all tracks on a media player
"Play (track, artist, album, genre or playlist + name of the track, artist, album, genre or playlist)"	Play tracks grouped as a artist, album, genre, and similar music or a play single track
"Similar Music"	To find and play all tracks similar to the one playing
"Shuffle On" / "Shuffle Off"	To randomly shuffle the order tracks are played in or to turn off this feature
"What's Playing"	To hear Sync speak a description of the track currently playing
"Pause"	To stop playing temporarily (Say "Play" to resume)
"Cancel"	To stop searching or playing music

<sup>1</sup> Note: For Navigation-equipped vehicles, from the main voice menu, you must first say "User Device" to access Sync Media Functions.

<sup>2</sup> Note: You may have to say "Phone" first to access Sync Phone Functions.

<sup>3</sup> For phones capable of call waiting, press the PHONE button to receive incoming calls and return to your previous call.

<sup>4</sup> For phones capable of call waiting, touch SEND to receive incoming calls and return to your previous call.

Updated: September 14, 2007

For more information, visit [SyncMyRide.com](http://SyncMyRide.com)